

Výrobce	Model
Acer	A100(vangogh)
Acer	Acer E320(C6)
Acer	E120(K2)
Acer	E130(K3)
Acer	E140(k4)
Acer	E210(k5)
Acer	E310(C4R)
Acer	E310(c4)
Acer	Liquid(a1)
Acer	Liquid Metal(a4)
Acer	Picasso(picasso)
Acer	Picasso(ventana)
Acer	S300(a5)
Apple	iPhone
Apple	iPhone 3G
Apple	iPhone 3GS
Apple	iPhone 4
Apple	iPhone 4S
Acer	Stream(a3)
Archos	ARCHOS 101G9(A101)
Archos	ARCHOS 80G9(A80)
Archos	Archos 101 Internet Tablet(A101S)
Asus	Eee Pad(EeePad)
Asus	Garmin-Asus A10(a10)
Asus	Garmin-Asus A50(a50)
Asus	Slider SL101(SL101)
Asus	Transformer TF101(TF101)
Asus	Transformer TF101G(TF101G)
Casio	Casio G'zOne Commando(C771)
Compal	Andy(cap2)
Compal	COSMO DUO(CA22)
Coolpad	8810(dkb)
Dell	BizSmartPhone(venue)
Dell	Dell Aero(Dell_Grappa)
Dell	Dell Streak(streak)
Dell	Dell Streak 10 Pro(Streak10Pro)
Dell	Dell Streak 7(streak7)
Enspert	ESP_E301VD(ESP_E301)
Enspert	enspert_e201(e201)
Foxconn	Axioo-VIGO410(vigo410)
Foxconn	CSL Spice MI700(mi700)
Foxconn	CSL-MI410(mi410)
Foxconn	Camangi-FM600(fm600)
Foxconn	Commtiva N700(n700)
Foxconn	Commtiva-HD710(hd710)
Foxconn	FIH-FB0(fb0)
Foxconn	Orange_Boston(Boston)
Foxconn	PICOpad-QGN(axioo)
Foxconn	V-T100(vt100)

Foxconn	ViewPad7(viewpad7)
Foxconn	WellcoM-A800(a800)
Foxconn	WellcoM-A99(a99)
Foxconn	cherry mobile-SUPERION(superion)
Foxconn	cherry-MagnumHD(magnumhd)
Foxconn	unknown(viewpad4)
Fujitsu Toshiba	REGZA Phone T01C(tg03)
Fujitsu Toshiba Mobile Communications Limited	F-12C(f11eif)
Fujitsu Toshiba Mobile Communications Limited	IS11T(TSI11)
Funai Electric	ALM-001J(smdkv210)
Gigabyte	GSmart G1310(G1310)
Gigabyte	GSmart G1315(G1315)
Gigabyte	GSmart G1317D(G1317D)
Gigabyte	GSmart G1317S(G1317S)
Google	Dell Streak(qsd8250_surf)
HTC	ADR6325(lexikon)
HTC	Aria(liberty)
HTC	Desire(bravo)
HTC	Desire(bravoc)
HTC	Desire HD(ace)
HTC	Desire S(saga)
HTC	Droid Eris(desirec)
HTC	Droid Incredible(inc)
HTC	EVO 3D(shooter)
HTC	EVO Shift 4G(speedy)
HTC	Evo 4G(supersonic)
HTC	Flyer(flyer)
HTC	G1(dream)
HTC	G2(vision)
HTC	HTC EVO 3D X515m(shooteru)
HTC	HTC Salsa C510e(icong)
HTC	HTC Status(chacha)
HTC	HTC_P515E(expresskt)
HTC	HTC_X515E(rider)
HTC	Hero(heroc)
HTC	Hero(hero)
HTC	Incredible 2(vivow)
HTC	Incredible S(vivo)
HTC	Legend(legend)
HTC	Nexus One(passion)
HTC	PG41200(express)
HTC	PH44100(kingdom)
HTC	Puccini(puccinilte)
HTC	Sensation 4G(pyramid)
HTC	Thunderbolt(mecha)
HTC	Wildfire(buzz)
HTC	Wildfire CDMA(bee)
HTC	Wildfire S(marvel)
HTC	myTouch 3G(sapphire)
HTC	myTouch 3G Slide(espresso)

HTC	myTouch 4G(glacier)
HTC	myTouch_4G_Slide(doubleshot)
Huawei	004HW(msm7227)
Huawei	007HW(hwu8850)
Huawei	A01HW(hwS7-901w)
Huawei	C8500(hwc8500)
Huawei	C8600(hwc8600)
Huawei	C8650(hwc8650)
Huawei	Express(hwm650)
Huawei	HUAWEI T8300(T8300)
Huawei	HUAWEI-M835(hwm835)
Huawei	HUAWEI-U9000(hwu9000)
Huawei	HUAWEI_IDEOS_U8500(hwu8500)
Huawei	Huawei U8800-51(hwu8800-51)
Huawei	IDEOS(U8150)
Huawei	IDEOS S7 Slim(qsd8k_slim)
Huawei	IDEOS X5(hwu8800)
Huawei	IDEOS X5(hwu8800Pro)
Huawei	IDEOS X5(msm7230)
Huawei	Ideos S7(qsd8k_s7)
Huawei	M860(M860)
Huawei	M860(msm7625)
Huawei	M865(hwm865)
Huawei	MTC_EVO(U8500)
Huawei	S42HW(hwS42HW)
Huawei	T-Mobile Pulse(U8100)
Huawei	TSP21(U8110)
Huawei	U8180(hwu8180)
Huawei	U8180(HuaweiU8180)
Huawei	U8220(U8220)
Huawei	U8230(hwu8230)
Huawei	U8230(msm7201a)
Huawei	U8300(U8300)
Huawei	U8300(msm7225)
Huawei	U8350(hwu8350)
Huawei	U8510(hwu8510)
Huawei	U8520(hwu8520)
Huawei	U8650(hwu8650)
Huawei	U8652(hwu8652)
Huawei	U880(U880)
Huawei	U8820(hwu8820)
Huawei	Vodafone 858(hwu8160)
Huawei	u8800(u8800)
INQ Mobile	INQ Cloud Touch -parrot(camden)
iRiver	ILT-MX100(smdkc110)
JVC KENWOOD Holdings, Inc.	RY-AP1(gener)
KT Tech	EV-S100(s100)
KT Tech	KM-S120(s120)
KT Tech	KM-S200(s200)
KT Tech	KM-S220(s220)

KYOCERA corporation	C5120(C5120)
KYOCERA corporation	M9300(M9300)
KYOCERA corporation	Zio(msm7627_surf)
KYOCERA corporation	Zio(SCP-8600)
KYOCERA corporation	Zio(pls8600)
Lenovo Mobile	A1_07(A1_07)
Lenovo Mobile	K1(K1)
Lenovo Mobile	Lenovo A60(lenovo73_cu)
Lenovo Mobile	ThinkPad Tablet(Indigo)
Lenovo Mobile	ThinkPad Tablet(18382AU)
LG	Ally(aloha)
LG	Optimus 2X(su660)
LG	Optimus 2X(p999)
LG	Optimus 2X(p990)
LG	Optimus Big(lu6800)
LG	Optimus Black(ku5900)
LG	Optimus Black(lgp970)
LG	Optimus Mach(lu3000)
LG	Optimus Mach(LU3000)
LG	Optimus One(thunderc)
LG	Optimus One(thunderg)
LG	Optimus One(lu3700)
LG	Optimus One(ku3700)
LG	Optimus One(su370)
LG	Optimus Pad(v900asia)
LG	Optimus Pad(v909mkt)
LG	Optimus Pad(v901tr)
LG	Optimus Pad(lu6900)
LG	Optimus Pad(v901kr)
LG	Optimus Pad(l06c)
LG	Optimus Pad(v901ar)
LG	Optimus Pad(v905r)
LG	Optimus Pad(v900)
LG	Optimus Pad(v909)
LG	Pecan(pecan)
LG	Swift(swift)
LGE	KU9500(ku9500)
LGE	L-04C(elini)
LGE	L-07C(L-07C)
LGE	LG-C550(hazel)
LGE	LG-C660h(muscat)
LGE	LG-C710h(alohag)
LGE	LG-E510f(univa_open-br)
LGE	LG-E510f(univa_tcl-mx)
LGE	LG-E510f(e510_724-XX)
LGE	LG-E720(alessi)
LGE	LG-E730(victor)
LGE	LG-KH5200(EVE)
LGE	LG-KU3700(thunder_kor-08)
LGE	LG-LS700(ls700)

LGE	LG-LS855(LS855)
LGE	LG-LU3000(hub)
LGE	LG-LU3100(lu3100)
LGE	LG-LU6500(bssq_450-06)
LGE	LG-P690(gelato_bal-xx)
LGE	LG-P690(gelato_cis-xx)
LGE	LG-P690(gelato_tur-xx)
LGE	LG-P690(gelato_eur-xx)
LGE	LG-P690(gelato_262-xx)
LGE	LG-P690(gelato_ngr-xx)
LGE	LG-P690(gelato_hkg-xx)
LGE	LG-P690(gelato_sea-xx)
LGE	LG-P920(p920)
LGE	LG-P925(p925)
LGE	LG-P925g(p925g)
LGE	LG-P970(LGP970)
LGE	LG-P990h(p990h)
LGE	LG-P990hN(p990hN)
LGE	LG-P993(p993)
LGE	LG-SU370(thunder_kor-05)
LGE	LG-SU660(star_450-05)
LGE	LG-SU760(su760)
LGE	LG-SU880(x2_450-05)
LGE	LG-V900(v900aus)
LGE	LG-V901(v901twn)
LGE	LG-VM701(VM701)
LGE	LG-VS700(VS700)
LGE	LU2300(lu2300)
LGE	SU950(su950)
LGE	USCC-US760(envt2)
LGE	VS910 4G(bryce)
LGE	VS920 4G(VS920)
Motorola	A1680(umts_lucky)
Motorola	Atrix(olympus)
Motorola	Backflip(motus)
Motorola	CLIQ(morrison)
Motorola	Cliq-XT(zeppelin)
Motorola	DROID BIONIC(cdma_targa)
Motorola	DROID3(cdma_solana)
Motorola	Defy(jordan)
Motorola	Defy(umts_jordan)
Motorola	Droid(umts_sholes)
Motorola	Droid(sholes)
Motorola	Droid II(cdma_droid2we)
Motorola	Droid II(cdma_droid2)
Motorola	Droid X(cdma_shadow)
Motorola	Droid X2(daytona)
Motorola	Glam XT800(titanium)
Motorola	MB200(morr)
Motorola	MB501(zepp)

Motorola	MB502(umts_basil)
Motorola	MB508(umts_sage)
Motorola	MB511(umts_ruth)
Motorola	MB520(umts_kobe)
Motorola	MB611(umts_begonia)
Motorola	MB612(cdma_kronos)
Motorola	MB855(sunfire)
Motorola	MOTWX435KT(Triumph)
Motorola	MT620(TAHITI)
Motorola	Milestone(A853)
Motorola	Milestone PLUS(cdma_venus2)
Motorola	Milestone2(umts_milestone2)
Motorola	Motoroi(sholest)
Motorola	Motorola-XT502(XT502)
Motorola	Spice(sesame)
Motorola	Titanium(rubicon)
Motorola	WX445(cdma_ciena)
Motorola	XOOM(stingray)
Motorola	XOOM(umts_hubble)
Motorola	XOOM(umts_everest)
Motorola	XOOM(wingray)
Motorola	XOOM(wifi_hubble)
Motorola	XT311(XT311)
Motorola	XT316(XT316)
Motorola	XT530(XT530)
Motorola	XT531(XT531)
Motorola	XT610(umts_venus2)
Motorola	XT711(choi)
Motorola	XT800+(cg_tita2)
Motorola	XT800W(ttu_skt)
Motorola	XT860(umts_solana)
Motorola	XT882(swordfish)
NEC	D000-000001-C01(LifeTouch_D1)
NEC	D000-000002-001(LifeTouch_W1)
NEC	D000-000010-N(D000000010N)
NEC	D000-000011-N(D000000011N)
NEC	IS11CA(IS11CA)
NEC	LT-NA7(LTNA7)
NEC	LT-NA7F(LTNA7F)
NEC	MEDIAS N-04C(N-04C)
NEC	MEDIAS N-06C(N-06C)
Nokia	500
Nokia	702T
Nokia	T7-00
Nokia	Oro
Nokia	E6-00
Nokia	X7-00
Nokia	C7 Astound
Nokia	C6-01
Nokia	C7-00

Nokia	E7-00
Nokia	N8-00
Nokia	C5-04
Nokia	C5-03
Nokia	5250
Nokia	5228
Nokia	5233
Nokia	C6-00
Nokia	5235 Ovi Music Unlimited
Nokia	N97 mini
Nokia	X6-00
Nokia	5230
Nokia	5530 XpressMusic
Nokia	N97
Nokia	5800 XpressMusic
Panasonic Mobile Communications	P-07C(pana1)
Panasonic Mobile Communications	P-07C(laputa)
Pantech	ADR8995(ADR8995)
Pantech	EIS01PT(mirachj)
Pantech	IM-A725L(ef14lv)
Pantech	IM-A730S(ef30s)
Pantech	IM-A760S(ef33s)
Pantech	IM-A770K(ef34k)
Pantech	IM-A780L(ef35l)
Pantech	IM-T100K(at1)
Pantech	IS06(jmasai)
Pantech	Izar(sp33k)
Pantech	Mirach(ef13s)
Pantech	Mirach(ef13l)
Pantech	PantechP8000(moon)
Pantech	PantechP9060(mini)
Pantech	Sirius(ef10s)
Pantech	Vega(ef12s)
Pantech	Vega X(ef14l)
Pantech	Vega X(ef18k)
Pantech	unknown(ef32k)
Pantech	unknown(ef31s)
Philips Electronics	Philips GoGear Connect(SA2CNTxx)
Philips Electronics	SA3CNT(Philips_GGC3)
Quanta Corporation	OP110(OP110)
Samsung	Acclaim(SCH-R880)
Samsung	Behold II(SGH_T939)
Samsung	Droid Charge(SCH-I510)
Samsung	Europa(GT-I5500B)
Samsung	Europa(GT-I5503)
Samsung	Europa(GT-I5500)
Samsung	Europa(GT-I5500L)
Samsung	Europa(GT-I5510)
Samsung	Europa(GT-I5510L)
Samsung	GT-B7510(GT-B7510)

Samsung	GT-B7510B(GT-B7510B)
Samsung	GT-B7510L(GT-B7510L)
Samsung	GT-I5500M(GT-I5500M)
Samsung	GT-I5503T(GT-I5503T)
Samsung	GT-I5508(GT-I5508)
Samsung	GT-I5510M(GT-I5510M)
Samsung	GT-I5510T(GT-I5510T)
Samsung	GT-I5700L(GT-I5700L)
Samsung	GT-I5800D(GT-I5800D)
Samsung	GT-I5800L(GT-I5800L)
Samsung	GT-I8150(GT-I8150)
Samsung	GT-I9001(GT-I9001)
Samsung	GT-I9008L(GT-I9008L)
Samsung	GT-I9018(GT-I9018)
Samsung	GT-I9100G(GT-I9100G)
Samsung	GT-I9100M(GT-I9100M)
Samsung	GT-I9100P(GT-I9100P)
Samsung	GT-I9100T(GT-I9100T)
Samsung	GT-I9108(GT-I9108)
Samsung	GT-P1010(GT-P1010)
Samsung	GT-P1013(GT-P1013)
Samsung	GT-P7300B(GT-P7300B)
Samsung	GT-P7500D(GT-P7500D)
Samsung	GT-P7500M(GT-P7500M)
Samsung	GT-P7500R(GT-P7500R)
Samsung	GT-S5360(GT-S5360)
Samsung	GT-S5360L(GT-S5360L)
Samsung	GT-S5570B(GT-S5570B)
Samsung	GT-S5570L(GT-S5570L)
Samsung	GT-S5578(GT-S5578)
Samsung	GT-S5660B(GT-S5660B)
Samsung	GT-S5660L(GT-S5660L)
Samsung	GT-S5660M(GT-S5660M)
Samsung	GT-S5660V(GT-S5660V)
Samsung	GT-S5670B(GT-S5670B)
Samsung	GT-S5670L(GT-S5670L)
Samsung	GT-S5820(GT-S5820)
Samsung	GT-S5830B(GT-S5830B)
Samsung	GT-S5830D(GT-S5830D)
Samsung	GT-S5830T(GT-S5830T)
Samsung	GT-S5838(GT-S5838)
Samsung	Galaxy 3(GT-I5800)
Samsung	Galaxy 3(GT-I5801)
Samsung	Galaxy A(archer)
Samsung	Galaxy Ace(SHW-M240S)
Samsung	Galaxy Ace(GT-S5830)
Samsung	Galaxy Ace(GT-S5830L)
Samsung	Galaxy Fit(GT-S5670)
Samsung	Galaxy Gio(GT-S5660)
Samsung	Galaxy Mini(GT-S5570)

Samsung	Galaxy Neo(SHW-M220L)
Samsung	Galaxy Player(YP-GB1)
Samsung	Galaxy Prevail(SPH-M820)
Samsung	Galaxy S(GT-I9003L)
Samsung	Galaxy S(GT-I9000T)
Samsung	Galaxy S(SCH-I400)
Samsung	Galaxy S(GT-I9000B)
Samsung	Galaxy S(GT-I9000M)
Samsung	Galaxy S(SGH-I897)
Samsung	Galaxy S(SHW-M190S)
Samsung	Galaxy S(SPH-D700)
Samsung	Galaxy S(SCH-I500)
Samsung	Galaxy S(SGH-T959)
Samsung	Galaxy S(SGH-T959V)
Samsung	Galaxy S(SCH-i909)
Samsung	Galaxy S(SC-02B)
Samsung	Galaxy S(SCH-R910)
Samsung	Galaxy S(SHW-M130K)
Samsung	Galaxy S(SHW-M110S)
Samsung	Galaxy S(GT-I9003)
Samsung	Galaxy S(GT-I9000)
Samsung	Galaxy S(SHW-M130L)
Samsung	Galaxy S(GT-I9010)
Samsung	Galaxy S2(SHW-M250K)
Samsung	Galaxy S2(SHW-M250L)
Samsung	Galaxy S2(SHW-M250S)
Samsung	Galaxy S2(GT-I9103)
Samsung	Galaxy S2(GT-I9100)
Samsung	Galaxy S2(SC-02C)
Samsung	Galaxy Spica(GT-I5700)
Samsung	Galaxy Tab(SHW-M180L)
Samsung	Galaxy Tab(SHW-M180K)
Samsung	Galaxy Tab(SPH-P100)
Samsung	Galaxy Tab(SHW-M180S)
Samsung	Galaxy Tab(SMT-i9100)
Samsung	Galaxy Tab(SGH-T849)
Samsung	Galaxy Tab(GT-P1000)
Samsung	Galaxy Tab(SCH-I800)
Samsung	Galaxy Tab(GT-P1000R)
Samsung	Galaxy Tab(GT-P1000T)
Samsung	Galaxy Tab(GT-P1000M)
Samsung	Galaxy Tab(GT-P1000N)
Samsung	Galaxy Tab(GT-P1000L)
Samsung	Galaxy Tab(SC-01C)
Samsung	Galaxy Tab 10.1(SHW-M380K)
Samsung	Galaxy Tab 10.1(SHW-M380S)
Samsung	Galaxy Tab 10.1(SHW-M380W)
Samsung	Galaxy Tab 10.1(GT-P7310)
Samsung	Galaxy Tab 10.1(GT-P7300)
Samsung	Galaxy Tab 10.1(SHW-M300W)

Samsung	Galaxy Tab 10.1(p3)
Samsung	Galaxy Tab 10.1(SCH-I905)
Samsung	Galaxy Tab 10.1(GT-P7500)
Samsung	Galaxy Tab 10.1(SGH-I957)
Samsung	Gem(SCH-I100)
Samsung	Infuse 4G(SGH-I997)
Samsung	Moment(SPH-M900)
Samsung	Nexus S(crespo4g)
Samsung	Nexus S(crespo)
Samsung	Replenish(SPH-M580)
Samsung	SAMSUNG-SGH-I777(SGH-I777)
Samsung	SAMSUNG-SGH-I857(SGH-I857)
Samsung	SAMSUNG-SGH-I997R(SGH-I997R)
Samsung	SCH-I110(SCH-I110)
Samsung	SCH-I405(SCH-I405)
Samsung	SCH-I559(SCH-I559)
Samsung	SCH-M828C(SCH-M828C)
Samsung	SCH-R680(SCH-R680)
Samsung	SCH-R720(SCH-R720)
Samsung	SCH-R730(SCH-R730)
Samsung	SCH-R915(SCH-R915)
Samsung	SCH-W899(SCH-W899)
Samsung	SCH-i559(SCH-i559)
Samsung	SCH-i569(SCH-i569)
Samsung	SCH-i579(SCH-I579)
Samsung	SCH-i579(SCH-i579)
Samsung	SCH-i809(SCH-i809)
Samsung	SGH-I987(SGH-I987)
Samsung	SGH-T499(SGH-T499)
Samsung	SGH-T499V(SGH-T499V)
Samsung	SGH-T499Y(SGH-T499Y)
Samsung	SGH-T589(SGH-T589)
Samsung	SGH-T589R(SGH-T589R)
Samsung	SGH-T759(SGH-T759)
Samsung	SGH-T959D(SGH-T959D)
Samsung	SGH-T959P(SGH-T959P)
Samsung	SHV-E110S(SHV-E110S)
Samsung	SHW-M135K(SHW-M135K)
Samsung	SHW-M180W(SHW-M180W)
Samsung	SHW-M290K(SHW-M290K)
Samsung	SHW-M290S(SHW-M290S)
Samsung	SPH-D600(SPH-D600)
Samsung	SPH-D710(SPH-D710)
Samsung	SPH-M930(SPH-M930)
Samsung	SPH-M930BST(SPH-M930BST)
Samsung	Sidekick 4G(SGH-T839)
Samsung	Transform(M920)(SPH-M920)
Samsung	VinsQ(M910)(SPH-M910)
Samsung	YP-G1(YP-G1)
Samsung	YP-G50(Non telephony)(YP-G50)

Samsung	YP-G70(YP-G70)
Samsung	YP-GB70(YP-GB70)
Samsung	YP-GS1(YP-GS1)
Samsung	unknown(SGH-I896)
Samsung	unknown(GT-P7510)
SEMC	Experia Acro(IS11S)
SEMC	Xperia Arc(SO-01C)
SEMC	Xperia Arc(LT15i)
SEMC	Xperia Play(Zeus)
SEMC	Xperia Play(R800i)
SEMC	Xperia X10(SO-01B)
SEMC	Xperia X10(X10i)
SEMC	Xperia X10 Mini(E10i)
SEMC	Xperia X10 Mini Pro(U20i)
SEMC	Xperia X8(E15i)
Sharp	A01SH(A01SH)
Sharp	Aquos(SBM006SH)
Sharp	Aquos(SH12C)
Sharp	DM009SH(DM009SH)
Sharp	EB-WX1GJ(Galapagos)
Sharp	Galapagos(SBM003SH)
Sharp	INFOBAR A01(SHX11)
Sharp	IS01(SHI01)
Sharp	IS03(SHI03)
Sharp	IS05(SHI05)
Sharp	IS11SH(SHI11)
Sharp	IS12SH(SHI12)
Sharp	Lynx 3D SH-03C(SH03C)
Sharp	SBM005SH(SBM005SH)
Sharp	SBM007SH(SBM007SH)
Sharp	SBM007SHJ(SBM007SHJ)
Sharp	SBM007SHK(SBM007SHK)
Sharp	SBM009SH(SBM009SH)
Sharp	SH-13C(SH13C)
Sharp	SH8128U(msm7627)
Sharp	SH8188U(SH8188U)
Sharp	SH8298U(SH8298U)
Sharp	SHARP-ADS1(ADS1)
SK Telesys	SK-S100(qsd8250_s1)
SK Telesys	SK-S150(msm8255_k5)
SK Telesys	SK-S170(K4)
Sony	Sony Tablet S(nbx03)
Sony Ericsson	R800at(R800at)
Sony Ericsson	R800x(R800x)
Sony Ericsson	SO-02C(SO-02C)
Sony Ericsson	SO-03C(SO-03C)
Sony Ericsson	WT18i(WT18i)
Sony Ericsson	X10a(X10a)
Sony Ericsson	unknown(MT15i)
TCT Mobile Limited (Alcatel)	ALCATEL one touch 890D(one_touch_890D_gsm)

TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_890(one_touch_890_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_891(one_touch_891_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_906Y(one_touch_906_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_906Y(OT-906)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_908(one_touch_908_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_908M(one_touch_908M_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_908S(one_touch_908S_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_990(one_touch_990_gsm)
TCT Mobile Limited (Alcatel)	ALCATEL_one_touch_990A(one_touch_990A_gsm)
TCT Mobile Limited (Alcatel)	Alcatel OT-980(msm7627_ffa)
TCT Mobile Limited (Alcatel)	Alcatel OT-980(OT-980_gsm)
TCT Mobile Limited (Alcatel)	Alcatel OT-980A(OT-980A_gsm)
TCT Mobile Limited (Alcatel)	Alcatel OT-981A(OT-981_gsm)
TCT Mobile Limited (Alcatel)	Alcatel OT-981A(OT-981A_gsm)
TCT Mobile Limited (Alcatel)	Alcatel one touch 990S(one_touch_990S_gsm)
TCT Mobile Limited (Alcatel)	I-L1(mercury)
TCT Mobile Limited (Alcatel)	MOVE(MOVE_gsm)
TCT Mobile Limited (Alcatel)	one touch 906(Martini)
Toshiba	AT100(tostab03)
Vizio Inc.	VTAB1008(VTAB1008)
ZTE	008Z(bladeplus)
ZTE	Android Edition StarText(turies)
ZTE	Android Edition Starnaute(amigo)
ZTE	Blade(blade)
ZTE	N720(N720)
ZTE	N721(N721)
ZTE	Racer(mooncake)
ZTE	RacerII(racer2)
ZTE	T3(skate)
ZTE	Vodafone 945(joe)
ZTE	ZTE-C N760(roamer)
ZTE	ZTE-C R750(r750)
ZTE	ZTE-T T9(T9)
ZTE	ZTE-T U830(U830)
ZTE	soft stone(P726N)